


FIRE/SMOKE DAMPER FREE AREA CONVERSION (1/FA)

WIDTH (INCHES)

	THE TT (MOTIES)									
		8	12	16	20	24	28	30	32	36
HEIGHT (INCHES)	8	4.75	2.85	2.05	1.60	1.30	1.20	1.10	1.05	1.00
	10	4.00	2.35	1.70	1.35	1.10	.920	.850	.825	.810
	12	3.35	2.05	1.45	1.15	.920	.775	.730	.710	.650
	14	2.60	1.60	1.15	.880	.720	.590	.565	.555	.500
	16	2.20	1.35	.925	.720	.590	.500	.465	.455	.400
	20	1.70	1.00	.725	.565	.465	.390	.365	.350	.310
	24	1.40	.835	.600	.465	.380	.325	.300	.285	.250
	28	1.15	.680	.485	.375	.310	.265	.245	.230	.205
	32	.995	.595	.425	.330	.275	.230	.215	.200	.180
	36	.880	.530	.380	.295	.240	.205	.190	.180	.160

Free area factors listed are for standard type "A" sleeves. For "D" type sleeves, free area conversion number is equal to 1/nominal duct area.




TO DETERMINE DAMPER PRES-SURE DROP:

- 1. Establish the free area conversion number (FA): Use the free area conversion table to determine the free area conversion number based on the damper width x height.
- (Example: 24"w x 24"h damper = .38 FA)
- **2.** Establish the conversion velocity (CV): Use the formula: CV = CFM x FA.
- (Example: CV = 4000 CFM x .38 FA) (CV = 1520 FPM)
- 3. Determine the pressure drop: Using the pressure drop table find the free area conversion number (.38) on the bottom line of the table.
- **4.** Project a line vertically locating the conversion velocity previously determined.
- **5.** Project this intersect horizontally to the left or right and read the pressure drop in inches of water. (Example: .03 inches W.G.)

Fusible Links for series FSD, CFSD & 2800 dampers:

#50a 165 degree fusible link, small


#52a212 degree fusible link, small#54a265 degree fusible link, small



Retaining Angle for Fire Dampers:

For 2800 Dynamic damper only:

- \bullet 1-1/2 x 1-1/2 x 16 gauge cold formed galvanized angle
- Pre-punched 7/32 holes for faster fastening of angle to sleeve
- Hole spacing is 3" on center



Rapid Mounting Angle for Fire Dampers:

- UL approved for all fire, smoke/fire damper installations in metal studs and concrete/masonary walls and floor
- Rapid Mounting Angle wraps around the sleeve, completing installation from one side.
- For field mounting

