

Using a small regular blade screw driver, insert this on the bottom end of the pad and pry up.



Once removed, the new pad can be set over the opening and snapped in place with your fingers.

