

INSTRUCTION

Shower Head Assembly

Model Number:







UF91000

UF91003

UF91005

Features:

- Single Function Shower Head
- Flow Rate :2.5 gallons-per-minute
- Shoewr Head Width:8"W



1.Insert shower arm through wall hole and thread to appropriate line . REMEMBER TO WRAP THREADED CONNECTIONS WITH TEFLON TAPE

2.Slide flange onto shower arm Push to wall

3.Attach shower head to shower arm by threading clock wise

INSTRUCTION

Shower Head Assembly

Model Number:







UF91000

UF91003

UF91005

Features:

- Single Function Shower Head
- Flow Rate :2.5 gallons-per-minute
- Shoewr Head Width:8"W



1.Insert shower arm through wall hole and thread to appropriate line . REMEMBER TO WRAP THREADED CONNECTIONS WITH TEFLON TAPE

2.Slide flange onto shower arm Push to wall

3.Attach shower head to shower arm by threading clock wise