

# DEFIANT ENCORE

**MODEL #:** 0028 / 2140 DEFIANT ENCORE

**FEATURES:** MODEL #0028 MANUFACTURED 7/11/86 THRU 4/25/90 WITH A GEISSER TESTING LAB. LABEL  
 MODEL #2140 MAUNFACTURED 5/17/90 THRU 11/5/91 WITH A WARNOCK HERSEY TESTING LABEL  
 CATALYST ACCESS IN THE BACK OF THE STOVE / DOUBLE PANE OF GLASS IN EACH DOOR

\* denotes dead product - not available

ITEM #	PART #	DESCRIPTION	ITEM #	PART #	DESCRIPTION
1	130-7410*	Bottom (no substitute)	47	130-7417	Upper Fireback Only
2	130-7411	Primary Air Frame Only		500-0335	Upper Fireback Ass'y (#47 to #51)
	500-0337	Primary Air Regulatory System (Includes #2,3,4, 5, 17, & 120-3518 Gasket)	48	130-7421	Damper Only
3	130-7412	Primary Air Valve Only	49	160-1488	Damper Tabs
4	160-1493	Primary Air Rod Only	50	160-1036	Torsion Bar (Damper Rod) Clip
5	30001794	Socket Set Sc Cable Adjust (rep 120-0645)	51	160-1035	Torsion Bar (Damper Rod)
6	130-7420	Ash Drop	52	160-1034	Damper Actuator Linkage
7	130-7435	Ash Drop Split Hinge Upper	53	160-1033	Damper Actuator Rod
8	130-7436	Ash Drop Split Hinge Lower	54	500-5470	Thermostat Coil & Rod Assembly c/w #55
9	130-7443	Ash Door (obsolete)	55	120-1864	Thermostat Eyelet Only
10	160-0622	Ashdoor Handle - Shaft Only	56	120-1846	Friction Spring
	160-0663	Ashdoor Wood Handle Only	57	130-7415	Thermostat Access Cup
11	500-4024	Pawl Assembly	58	500-4265	Damper Handle Stub Nickel c/w Set Screw
11a	120-3290	Large Jam Nut for Pawl Assembly	59	130-7423	Damper Link Access Panel
12	120-3004	Cash Door Hinge Pin	60	130-7434	Bottom Grate
12a	120-3031	Cotter Pin #13	61	500-4224	Thermostat Handle Complete
13	160-1039	Ash Pan Bracket		160-0660	Thermostat Wooden Handle Only
14	See Chart	Ashlip		500-4264	Thermostat Handle Stub c/w Set Screw
15	See Chart	Leg		120-1243	Thermostat Handle Long Screw Only
16	160-0600	Handle Bracket	62	130-7442*	Catalyst Access Panel (no substitute)
17	500-5471	Primary Air Cable c/w 2 Sleeves	63	160-1489	Secondary Air Probe
18	130-8609	Primary Air Cover Plate (rep 130-7418)	64	160-1490	Secondary Air Flap
19	See Chart	Front	65	120-1986	Secondary Air Shim Ring
20	See Chart	Left Door Only	66	160-1486	Secondary Air Link
21	160-1396	Glass Clip Long .75"	67	160-1492	Secondary Air Cover Plate
22	130-7402	Door Hinge Plate	68	140-1115	Glass (1)
23	160-0416	Upper Door Hinge Pin	69	500-2789	Glass Gasket With Wire (Between Glass)
24	160-0417	Lower Door Hinge Pin		120-3537	Interam Gasket 9" Under the Glass
25	120-1985	Jump Ring	70	130-7419	Andiron
26	130-7403	Left Door Manifold	71	130-0797	Griddle (No Quads)
27	See Chart	Right Door Only	72	130-0809	Griddle Quad Straight (1)
28	160-1394	Glass Clip Short .62"		000-4444	Griddle Quad Straight (1) with Bolt
29	130-7404	Right Door Manifold	73	160-1025	Ash Pan Only
30	30001759	Handle Stub w/ Set Screw (repl 500-4225)	74	160-1027	Ash Pan Cover With Handle
31	130-7424	Front Air Manifold (obsolete)		500-5746	Ash Pan & Cover Assembly (#73 & # 74)
32	See Chart	Left End	75	500-4022	Griddle Handle Complete
33	See Chart	Right End		160-0658	Griddle Handle Stub Only
34	See Chart	Top		160-0661	Griddle Handle Wood Knob Only
35	See Chart	Back		120-1900	Griddle Handle Bushing Only (2 used)
36	See Chart	Flue Collar		120-1308	Griddle Handle Wood Handle Screw
37	130-7413	Left Air / Wear Plate		120-3210	Griddle Handle Wood Handle Nut Only
38	130-7414	Right Air / Wear Plate	76	000-4342	Fallaway Handle Complete (#85, #77, #78)
39	160-8629	Left Deflector	77	160-0620	Ceramic Handle - Ceramic Part Only
40	160-8630	Right Deflector	78	160-0650	Ceramic Handle Chrome Nub Only
41	500-4600	Refractory Assembly (w/ Access Panel)	79	120-1294	Ceramic Handle - Screw Only
42	160-2503	Access Panel Only	80	160-0664	Damper Handle Wood Handle Only
43	30001152	Catalyst Block	81	120-2471	1/4" SS Flat Washer
44	160-2506	Heat Exchanger	82	120-2560	3/8" Narrow Flat Washer
45	160-2507	Refractory Cover (SS Piece On Top)	83	120-6115	Kawool 3/4" x 7" (4 Used)
46	130-7416	Lower Fireback	84	120-1310	Damper Handle Screw Only