

## **PX25 instructions**

### **Battery Installation**

- Turn the end cap in a counter-clockwise direction to remove the cap.
- Remove the battery cartridge.
- Place three AAA batteries into the cartridge in the direction indicated on the cartridge.
- Replace the cartridge in the light with the red end going in first.
- Replace the tail cap and turn it clockwise to tighten it until it is fully closed.

### **On/Off Operation**

- The PX25 has a rear switch on the tail cap.
- To turn on the light, press the switch fully until it “clicks.”
- To turn off the light, press the switch fully until it “clicks.”
- The light can also be operated in “momentary” mode. Momentary mode is activated by partially depressing the on/off switch (less pressure than required for a full click).