



# EVAPORATIVE COOLER PARTS

# WATER DISTRIBUTOR PARTS

DIAL P/N	DESCRIPTION / PACKAGING	PKG	CTN QTY	CTN WT
----------	-------------------------	-----	---------	--------

## WATER DISTRIBUTOR ACCESSORIES

▲4619	Water Distributor Adapter	Connects pump hose to water distributor head. 1/2 I.D. Barb x 1/4 MPT 120° angle.	▲ Bag	10	0.2
4621	Water Distributor Adapter		Bulk	50	0.6
▲4625	Water Distributor Adapter		Clam	8	0.2
4630	Tube Retainer Clip	Support clip for water distributor tubes, prevents sagging and movement. Replacement for Arctic Circle® coolers.	Bulk	50	0.4
▲4631	Tube Retainer Clip (4 per)		Bag	10	0.3
▲4632	Tube Retainer Clip (4 per)		Clam	10	0.4
▲4633	Tube Retainer Clip (4 per)		▲ Bag	10	1.0
4626	Tube Retainer Clip for Champion®	Same as above except for Champion® coolers.	Bulk	50	0.3
▲4627	Tube Retainer Clip for Champion® (4 per)		Clam	10	0.4
▲4629	Tube Retainer Clip for Champion® (4 per)		▲ Bag	10	1.0
▲4622	Dist. Tube Latch for Tradewinds™ (4 per)	Same as above except for Tradewinds™ coolers.	Clam	10	0.4
4637	18-1/2" Distributor Tube	18½" (end to bend length) - 3/8" O.D. - cut to fit many coolers.	Bulk	100	5.4
4638	20-1/8" Distributor Tube	Same except 20-1/8" (end to bend) - fits all residential coolers.	Bulk	100	6.1
▲4643	20-1/8" Distributor Tube	Same except 200 per display box.	Box	200	11.6
▲4648	20-1/8" Distributor Tube (4 per)	Same except 4 per bag.	Bag	10	2.6
4674	MEK Distributor Tube Solvent	Methyl Ethyl Ketone...solvent for welding tubes to distributor heads.	Bulk	10	0.2
▲4689	MEK Distributor Tube Solvent		Clam	6	0.2
▲4690	24" Spider Snake™	Flexible Snake bends 90° to remove scale and wood pulp debris from water distributor tubes.	Label	10	0.9
▲4691	24" Spider Snake™		▲ Clam	10	1.5
▲4693	60" Pump Hose and Water Distributor Snake	Extended length Snake bends 90° to remove scale and wood pulp debris from water distributor tubes and pump hose.	Label	10	1.7
▲4694	60" Pump Hose and Water Distributor Snake		Clam	10	2.0
4662	Water Distribution Meter Tip	13/64" I.D. black meter tip for industrial and other coolers using a perimeter PVC pipe water distribution system.	Bulk	10	0.04



## WATER DISTRIBUTOR HEADS

4713	3 Way Side Distributor Head		Bulk	12	0.4
▲4718	3 Way Side Distributor Head	Standard OEM style water distributor head. Must be welded to tubes using MEK solvent to prevent water damage to motor and pump. Accepts 10 x 1/2 Phillips Pan tapping screw. Screw not included.	Bag	12	0.6
4724	4 Way Side Distributor Head		Bulk	12	0.5
4732	6 Way Side Distributor Head		Bulk	12	0.5
▲4737	6 Way Side Distributor Head		Clam	12	0.7
▲4759	4 Way Down Distributor Head		Clam	12	0.7
4770	8 Way Down Distributor Head		Bulk	12	0.6
▲4775	8 Way Down Distributor Head		Clam	12	0.8




## WATER TROUGHS / DRIP TRAYS

▲4798	20" Water Trough for Champion®		Lbl	6	5.5
▲4799	24" Water Drip Tray		Lbl	6	4.7
▲4800	28" Water Trough	Replacement trays or troughs for Champion® and other coolers.	Lbl	6	5.3
▲4801	26" Water Trough for Champion®		Lbl	6	5.3
▲4802	30¾" Water Trough for Champion®		Lbl	6	7.7
▲4803	32" Water Trough for Champion®		Lbl	6	7.9



## PAD FRAME LATCHES

4791	Pad Frame Latch Assembly	Replacement latch for Arctic Circle®, Arvin® and McGraw® coolers, may be retrofitted to all coolers. Sun resistant polypropylene.	Bulk	10	0.2
▲4792	Pad Frame Latch Assembly (2 per)		Bag	10	0.4
▲4793	Pad Frame Latch Assembly (2 per)		Clam	10	0.5
4795	Metal Pad Frame Latch	Replacement for Arctic Circle® coolers with metal latches. Mounting screw included.	Bulk	10	0.3
▲4797	Metal Pad Frame Latch (2 per)		Clam	10	0.9
▲4786	Corner Wire Latch for Tradewinds™	Replacement corner wire latch for newer Tradewinds™ coolers. Wire.	Clam	10	0.5



▲ Display Carton with tear-away lid / ▲ UPC Items