




## SERVICE PARTS LIST

**BULLETIN NO.**  
**54-05-8960**

| SPECIFY CATALOG NO. AND SERIAL NO. WHEN ORDERING PARTS |                | REVISED BULLETIN                               | DATE        |
|--------------------------------------------------------|----------------|------------------------------------------------|-------------|
| <b>8 GALLON DUST EXTRACTOR</b>                         |                |                                                | May 2017    |
| <b>CATALOG NO.</b>                                     | <b>8960-20</b> | <b>STARTING SERIAL NO.</b>                     | <b>J08A</b> |
|                                                        |                | <b>WIRING INSTRUCTION</b><br><b>See Page 6</b> |             |

**EXAMPLE:**  
00 0 Component Parts (Small #) Are Included  
When Ordering The Assembly (Large #).


| FIG. | PART NO.   | DESCRIPTION OF PART    | NO. REQ. |
|------|------------|------------------------|----------|
| 1    | 43-98-0011 | Rotary Knob            | (1)      |
| 2    | 34-40-0241 | O-Ring                 | (1)      |
| 3    | 06-82-0127 | 2.9 x 19 ST Screw      | (1)      |
| 6    | 23-66-0069 | Rotary Switch          | (1)      |
| 7    | 23-45-0100 | Potentiometer Assembly | (1)      |
| 8    | 42-52-0021 | Cap                    | (1)      |
| 9    | 34-40-0242 | O-Ring                 | (1)      |
| 10   | 43-98-0012 | Turning Knob Assembly  | (1)      |





| FIG. | PART NO.   | DESCRIPTION OF PART           | NO. REQ. |
|------|------------|-------------------------------|----------|
| 11   | 23-33-0066 | Outlet Receptacle             | (1)      |
| 12   | 23-35-0141 | Control Panel Kit             | (1)      |
| 13   | 43-62-0211 | Handle Kit                    | (1)      |
| 14   | 06-82-0129 | K50 x 45 Screw                | (3)      |
| 15   | 42-92-0301 | Top Cover                     | (1)      |
| 16   | 06-82-0132 | 5 x 18 Screw                  | (17)     |
| 17   | 31-21-0300 | Hatch Door                    | (1)      |
| 18   | 45-56-0045 | Cord Strap Kit                | (1)      |
| 19   | 42-68-0135 | Hatch Door Clamp Kit          | (1)      |
| 20   | 42-92-0302 | Hatchback Lower Cover         | (1)      |
| 21   | 43-72-0005 | Hose/Cable Hook               | (2)      |
| 22   | 14-46-1141 | Control Panel Label Kit       | (1)      |
| 23   | 12-20-0117 | Service Nameplate (Not Shown) | (1)      |

|               |                                                                        |
|---------------|------------------------------------------------------------------------|
| <b>Page 1</b> | <b>Cabinet and Control Panel</b>                                       |
| <b>Page 2</b> | <b>Filter Cleaning System</b>                                          |
| <b>Page 2</b> | <b>Suction Unit, Floater/Reed Sensor, Flow Sensor, Buzzer and PCBA</b> |
| <b>Page 3</b> | <b>Baseplate</b>                                                       |
| <b>Page 4</b> | <b>30L Container</b>                                                   |
| <b>Page 5</b> | <b>Hose, Attachments and Filters</b>                                   |
| <b>Page 6</b> | <b>Wiring Diagram</b>                                                  |


**AS AN AID FOR SERVICING, REFER TO REPAIR INSTRUCTION MANUAL 58-92-8960**




| FIG. | PART NO.   | DESCRIPTION OF PART          | NO. REQ. |
|------|------------|------------------------------|----------|
| 1    | 42-92-0303 | Hatch Door Frame Assembly    | (1)      |
| 2    | 06-82-0129 | 5 x 18 Screw                 | (15)     |
| 3    | 23-84-0110 | Solenoid Kit                 | (1)      |
| 4    | 06-82-0137 | PT35 x 18 Screw              | (2)      |
| 5    | 42-68-0500 | Cord Clamp                   | (1)      |
| 6    | 43-44-0125 | Hatch Door Filter Gasket Kit | (1)      |
| 7    | 49-90-1953 | Main Filter                  | (1)      |




| FIG. | PART NO.   | DESCRIPTION OF PART                | NO. REQ. |
|------|------------|------------------------------------|----------|
| 1    | 44-52-0005 | Foam Pad                           | (1)      |
| 2    | 43-70-0033 | Hatch Door Hinge (Set of two)      | (1)      |
| 3    | 23-45-2005 | Reed Sensor Assembly               | (1)      |
| 4    | 22-09-0465 | Circuit Board Assembly             | (1)      |
| 5    | 06-82-0137 | 3.5 x 18 Screw                     | (2)      |
| 6    | 42-68-0501 | Cord Clamp                         | (1)      |
| 7    | 44-52-0425 | Filter Block                       | (1)      |
| 8    | 42-92-0304 | Filter Cover                       | (1)      |
| 10   | 23-30-0550 | Motor Kit                          | (1)      |
| 11   | 22-18-0595 | Carbon Brush Assembly (Set of two) | (1)      |
| 12   | 42-14-0315 | Air Guide Housing                  | (1)      |
| 13   | 06-82-0129 | 5 x 18 Screw                       | (9)      |
| 14   | 23-94-0570 | Wire Harness/Capacitor Kit         | (1)      |




| FIG. | PART NO.   | DESCRIPTION OF PART | NO. REQ. |
|------|------------|---------------------|----------|
| 1    | 43-31-0025 | Sound Filter        | (1)      |
| 2    | 06-82-0137 | 3.5 x 18 Screw      | (2)      |
| 3    | 42-68-0501 | Cord Clamp          | (1)      |
| 4    | 43-72-0340 | Distribution Strip  | (1)      |
| 5    | 42-68-0502 | Container Clamp     | (2)      |
| 6    | 22-64-0935 | Power Cord          | (1)      |




|    |            |                                  |     |
|----|------------|----------------------------------|-----|
| 7  | 42-20-0375 | Base Plate Assembly Kit          | (1) |
| 8  | 23-94-0395 | Anti-Static Ground Clip Assembly | (1) |
| 9  | 44-26-0022 | Floater with Magnet              | (1) |
| 10 | 06-82-0139 | K50 x 18 PT Screw                | (4) |
| 11 | 42-92-0305 | Air Flow Cover Kit               | (1) |
| 12 | 43-44-0995 | Container Gasket                 | (1) |





| FIG. | PART NO.   | DESCRIPTION OF PART           | NO. REQ. |
|------|------------|-------------------------------|----------|
| 1    | 45-66-0160 | 30L Container                 | (1)      |
| 3    | 45-94-0505 | Castor Wheel Kit (Set of two) | (1)      |
| 4    | 06-82-0146 | K50 x 35 Screw                | (1)      |
| 5    | 42-12-0310 | Wheel Axle                    | (1)      |
| 6    | 45-94-0507 | Rear Wheel                    | (2)      |
| 7    | 34-80-2985 | Clamping Ring                 | (2)      |
| 8    | 42-52-0180 | Wheel Cap                     | (2)      |
| 9    | 44-68-0015 | Hose Inlet Plug               | (1)      |
| 10   | 42-60-0205 | 150mm Bead Chain              | (1)      |
| 11   | 06-82-0147 | KA35 x 8 Screw                | (1)      |



| FIG. | PART NO.   | DESCRIPTION OF PART      | NO. REQ. |
|------|------------|--------------------------|----------|
| 2    | 43-75-0300 | Hose                     | (1)      |
| 3    | 42-04-0260 | Quick System Hose Sleeve | (1)      |
| 4    | 42-04-0265 | Hose Sleeve              | (1)      |
| 7    | 49-90-1957 | Power Tool Adapter       | (1)      |
| 17   | 49-90-1958 | Vacuum Hose Adapter      | (1)      |
| 18   | 49-90-1959 | DEK26 Adapter            | (1)      |
| 19   | 49-90-1960 | DE Adapter               | (1)      |

2

7



17

18



19

| FIG. | PART NO.   | DESCRIPTION OF PART            |
|------|------------|--------------------------------|
| 1    | 49-90-1953 | Main Filter                    |
| 2    | 43-31-0005 | Motor Cooling Air Filter       |
| 3    | 49-90-1952 | HEPA FILTER                    |
| 4    | 42-92-0306 | HEPA Filter Cover Kit          |
| 5    | 49-90-1954 | Disposable Filter Bag - 5 Pack |
| 7    | 49-90-1955 | Fleece Filter Bag - 5 Pack     |

| NO. REQ. |
|----------|
| (1)      |
| (1)      |
| (1)      |
| (1)      |
| (1)      |
| (1)      |



5



4

7

