


OLD Optima® ETF-80/ETF-880



OLD-STYLE FAUCETS

ETF-80 faucets manufactured before 1992 had all their electronic circuitry located within the body of the spout.

Replacement parts (including sensor components) are available in repair kits ETF-1006-A. — **OBSOLETE**


PARTS LIST—ETF-80 AND ETF-880 FAUCETS				
Item No.	Code No.	Part No.	Description	
1A.	0305613	ETF-250-A	Faucet/Sensor Assembly (ETF-80)	
	0365054	ETF-625-A	Faucet/Sensor Assembly (ETF-880)	
1B.	3365523	ETF-631-A	Sensor Assembly Only (for Faucets manufactured after 10/2003, identified by an all white Sloan name on throat plate) (ETF-80). For ETF-80 faucets prior to 10/2003 (identified by a white and red Sloan name on throat plate) sensor assembly discontinued. Use ETF-250 faucet/sensor assembly.	
	OBSOLETE	ETF-1031	Repair Kit Throat Plate and Sensor (ETF-880)	
2.	3365091	ETF-1021-A	0.5 gpm (1.9 Lpm) Spray Head with Key (female thread)	
	3365090	ETF-1022-A	2.2 gpm (8.3 Lpm) Aerator Spray Head with Key (female thread)	
	3365161	ETF-1028-A	1.5 gpm (5.7 Lpm) Laminar Flow Spray Head with Key (female thread) $$	
	3365755	ETF-1038-A	0.35 gpm (1.3 Lpm) Multi-Lam Spray Head VR	
3.	0305927	ETF-435	Replacement Key ONLY	
4A.	3365466	ETF-295-A	4" (102 mm) Centerset Trim Plate Kit for Faucet (Faucet Only) includes two (2) Nuts, two (2) Hex Screws, two (2) Flat Washers, Single Hole Cover Plate, and CP Base Plate (ETF-80)	
_	3365467	ETF-299-A	4" (102 mm) Centerset Trim Plate Kit for Faucet with Optional Mixing Valve includes two (2) Nuts, two (2) Hex Screws, two (2) Flat Washers, Dual Hole Cover Plate, and CP Base Plate (ETF-80)	
4B.	3365473	ETF-662-A	4" (102 mm) Centerset Trim Plate Kit (CP) (ETF-880)	
4C.	3365024	ETF-510-A 8" (203 mm) Centerset Trim Plate Kit includes two (2) Finger Nuts, two (2) Washer Gaskets, two (2) Fender Washers, Base Gasket, Back-up Spacer and CP Single Hole Trim Plate Assembly (CP) (ETF-880)		
5.	0305626	ETF-290-A Faucet Mounting Kit includes Rubber Gasket, Mounting Washer, Mounting Nut, and 4439071 Compression Fitting Connector		
6.	0305736	ETF-297	1/4" to 3/8" Compression Fitting Connector	
7A.	0305849	ETF-370-A	24 VAC Solenoid Valve Assembly includes 18" (457 mm) armored Cable and two (2) Terminal Housings	
7B.	3305577	ETF-1009-A	•	
7C.	3365676	ETF-437-A Single Solenoid Supply Kit includes, two (2) Compression Fittings (Supplied only with complete faucet)		
7D.	3375003	MCR-1003-A	Diaphram only	
8.	3365000	ETF-450-A	Control Module Assembly includes splashproof Junction Box and Junction Box Mounting Kit	
9.	0365534	ETF-233	120V/35VA Plug-In Transformer	
10.	0345370	EL-248-40	-	
11.	0365001	ETF-458-A Input Power Cable (Transformer to Control Module includes Strain Relief and two (2) Terminal Crimp Connectors		
12.	3365461	ETF-617-A	Bak-Chek® Tee Assembly	
_	3305560	(n 5, 5 Pl	epair Kit for old-style ETF-80 Faucets nanufactured before 1992) includes Hex Screw, '64" Hex Wrench, Cable Assembly, Hose Clamp, -connector Housing, Key for Spray Heads, Access ate/Sensor Assembly, and Control Module Assembly OBSOLETE	


See page 157 for faucet cable extension cords.

--- = Not shown in illustration



OLD Optima® ETF-600/ETF-610






PARTS LIST-ETF-600 AND ETF-610 FAUCETS

Item				
No.	Code No.	Part No.	Description	
1A.	0365086	ETF-543-A	Faucet and Sensor Assembly (ETF-600)	
1B.	0365117	ETF-570-A	Pedestal Faucet and Sensor Assembly (ETF-610)	
1C.	0365070	ETF-542-A	Sensor Module Only (for ETF-600 and ETF-610 faucets) includes 18" (153 mm) armored Cable, Shroud, and Housing for Sensor Window	
2.	3365092	ETF-1023-A	0.5 gpm (1.9 Lpm) Spray Head with Key (male thread)	
	3365093	ETF-1024-A	2.2 gpm (8.3 Lpm) Aerator Spray Head with Key (male thread)	
	3365162	ETF-1029-A	2.2 gpm (8.3 Lpm) Laminar Flow Spray Head with Key (male thread)	
	3365756	ETF-1039-A	0.35 gpm (1.3 Lpm) Multi-Lam Spray Head VR	
3.	0305927	ETF-435	Replacement Key Only	
4A.	3365088	ETF-546-A	Faucet Mounting Kit for ETF-600 includes Base Gasket, two (2) Slotted Mounting Washers, two (2) Wing Nuts, and Compression Fitting Connecto	
4B.	0315085	EBF-123-A	Faucet Mounting Kit for ETF-610 includes Spacer, Base Gasket, 1/4" NPSM Hex Nut, Washer, 9/16" Lock Washer and Compression Fitting Connector	
5.	0365058	ETF-547	1/8" NPT Pipe to 3/8" Tube Compression Fitting Connector (female)	
6.	3365676	ETF-437-A	Single Solenoid Supply Kit includes, two (2) Compression Fittings, Compression Nut, and Ferrule	
7A.	0305849	ETF-370-A	24 VAC Solenoid Valve Assembly includes 18" (457 mm) armored Cable and two (2) Terminal Housings	
7B	3305577	ETF-1009-A	Solenoid Valve Repair Kit includes Replacement Filter, Guide, Armature Spring, Diaphragm and Washer	
7C.	3375003	MCR-1003-A	A Diaphram only	
8.	3365000	ETF-450-A	Control Module Assembly includes splashproof Junction Box and Junction Box Mounting Kit	
9.	0365534	ETF-233	120V/35VA Plug-In Transformer	
10.	0345370	EL-248-40	24V/40VA Box Mount Transformer	
11.	0365001	ETF-458-A	Input Power Cable (Transformer to Control Module) includes Strain Relief and two (2) Terminal Crimp Connectors	
12.	3365461	ETF-617-A	Bak-Chek® "T" Assembly	

See page 157 for faucet cable extension cords.


--- = Not shown in illustration






OLD Optima® ETF-700/ETF-700-S





Optional Trim Plates



PARTS LIST—ETF-700 FAUCET

Item No.	Code No.	Part No.	Description	
1A.	0365108	ETF-472-A	Faucet and Sensor Assembly with Standard Gooseneck Spout (ETF-700)	
1B.	0365109	ETF-473-A	Faucet and Sensor Assembly with Surgical Bend Gooseneck Spout (ETF-700-S)	
1C.	0365456PK	ETF-830-A	(NEW STYLE) Sensor Module Only includes 18" (153 mm) armored Cable, Shroud, and Housing for Sensor Window (ETF-700 and ETF-700-S Faucets)	
1C.	0365028	ETF-476-A	(OLD STYLE) (Prior to 1-2009) Sensor Module Only includes 18" (153 mm) armored Cable, Shroud, and Housing for Sensor Window (ETF-700 and ETF-700-S Faucets)	
2A.	0365147	ETF-621-A	2.2 gpm (8.3 Lpm) Aerator Spray Head with Key (female thread)	
	0365793	ETF-839	0.35 gpm (1.3 Lpm) Multi-Lam Spray Head	
2B.	0328134	AC-55-A	Shower Spray Head Assembly, 2.2 gpm (8.3 Lpm)	
3.	0305784	ETF-178	Adapter for Spray Heads (not required for AC-55-A Shower Spray Head)	
4.	0365110	ETF-503-A	Spout Mounting Kit Includes Rubber Washer, Flat Washer, Lockwasher, Mounting Nut, and Union Compression Fitting	
5.	0365057	ETF-530	3/8" x 3/8" Union Compression Fitting (female)	
6.	3365676	ETF-437-A	Single Solenoid Supply Kit includes, two (2) Compression Fittings, Compression Nut, and Ferrule	
7A.	0305849	ETF-370-A	24 VAC Solenoid Valve Assembly includes 18" (457 mm) Armored Cable and two (2) Terminal Housings	
7B.	3305577	ETF-1009-A	Solenoid Valve Repair Kit includes Replacement Filter, Guide, Armature Spring, Diaphragm and Washer	
7C.	3375003	MCR-1003-A	Diaphram only	
8.	3365461	ET617-A	Bak-Chek® "T" Assembly	
9.	3365000	ETF-450-A	Control Module Assembly includes splashproof Junction Box and Junction Box Mounting Kit	
10.	0365534	ETF-233	120V/35VA Plug-In Transformer	
11.	0345370	EL-248-40	24V/40VA Box Mount Transformer	
12.	0365001	ETF-458-A	Input Power Cable (Transformer to Control Module) includes Strain Relief and two (2) Terminal Crimp Connectors	
13.	0305927	ETF-435	Replacement Key Only	
14.	3365302	ETF-607-A	Trim Plate for 4" Center-set Sink	
15.	3365303	ETF-608-A	Trim Plate for 8" Center-set Sink	


^{--- =} Not shown in illustration


FAUCET CABLE EXTENSION CORDS ETF-80, ETF-500, ETF-600/ETF-610, ETF-660/ETF-770, ETF-700


L11 00, L11	000, E11 000/	EII 010, EII 000/EII 770, EII 700
0365042	ETF-1005-26	Faucet to Control Module Extension Cord; 26 inch (0.7 meter) Length — OBSOLETE
0305861	ETF-1005-36	Faucet to Control Module Extension Cord; 36 inch (0.9 meter) Length
0305862	ETF-1005-72	Faucet to Control Module Extension Cord; 72 inch (1.8 meter) Length – OBSOLETE
0305863	ETF-1005-108	Faucet to Control Module Extension Cord; 108 inch (2.7 meter) Length
0365838	ETF-1003-36	Solenoid to Control Module Extension Cord; 36 inch (0.9 meter) Length
0365053	ETF-1003-48	Solenoid to Control Module Extension Cord; 48 inch (1.2 meter) Length — OBSOLETE
0365839	ETF-1003-72	Solenoid to Control Module Extension Cord; 72 inch (1.8 meter) Length — OBSOLETE
0365840	ETF-1003-108	Solenoid to Control Module Extension Cord; 108 inch (2.7 meter) Length




OLD Optima® ETF-500/ETF-500-S


















New Base Gasket

The new base gasket (in production since October 1999) is shown at right. An older base gasket design did not have the u-shaped drainage hole.



PARTS LIST-ETF-500 FAUCET

Item No.	Code No.	Part No.	Description	
1A.	0365778	ETF-772-A-ST	-	
1B.	0365783	ETF-772-A-SU	Faucet/Sensor Assembly with Surgical Bend Gooseneck Spout	
2.	0305784	ETF-178	Aerator Adapter for Spray Heads (not required for AC-55-A Shower Spray Head)	
3A.	0365147	ETF-621-A	2.2 gpm (8.3 Lpm) Aerator Spray Head with Key (female thread)	
	0365793	ETF-839	0.35 gpm (1.3 Lpm) Multi-Lam Spray Head	
	0305927	ETF-435	Replacement Key ONLY	
3B.	0328134	AC-55-A	Shower Spray Head Assembly, 2.2 gpm (8.3 Lpm)	
4.	0315060	EBF-110-A	Faucet Mounting Kit includes Base Gasket, large Flat Washer, large Lock Washer, large Nut, Mounting Spacer, Mounting Stud, small Flat Washer, small Lock Washer, small Nut, Anti-Rotation Screw, and Compression Fitting Connector (male)	
_	0365152	ETF-591	1/8" NPT Pipe to 3/8" Tube Male Compression Fitting Connector	
5.	3365676	ETF-437-A	Single Solenoid Supply Kit includes, two (2) Compression Fittings, Compression Nut, and Ferrule	
6A.	0305849	ETF-370-A	24 VAC Solenoid Valve Assembly includes 18" (457 mm) armored Cable and two (2) Terminal Housings	
6B	3305577	ETF-1009-A	Solenoid Valve Repair Kit includes Replacement Filter, Guide, Armature Spring, Diaphragm and Washer	
6C.	3375003	MCR-1003-A	Diaphram only	
7.	3365461	ETF-617-A	Bak-Chek® "T" Assembly	
8.	3365000	ETF-450-A	Control Module Assembly includes splashproof Junction Box and Junction Box Mounting Kit	
9.	0365534	ETF-233	120V/35VA Plug-In Transformer	
10.	0345370	EL-248-40	24V/40VA Box Mount Transformer	
11.	0365001	ETF-458-A	Input Power Cable (Transformer to Control Module) includes Strain Relief and two (2) Terminal Crimp Connectors	
12.	0365097	ETF-568-A	Sensor Only	

See page 157 for faucet cable extension cords.

--- = Not shown in illustration

OLD MOUNTING KIT AND FAUCET SHANK


12.	N/A ^{††}	EBF-110-A	Old Faucet Mounting Kit included 3/8" Water Supply Tube, Base Gasket, large Flat Washer, large Lock Washer, large Nut, and Compression Fitting Connector (order Items 4 and 13 as replacement parts)
13.	0365058	ETF-547	1/8" NPT Pipe to 3/8" Tube Female Compression

The new mounting kit (in production since June 1999; Item 4 shown at left) includes parts for installation on both thin and thick surfaces, an ETF-591 male compression fitting, and an anti-rotation screw for installation on sheet metal surfaces less than 0.41" (10 mm) thick. For surfaces between 0.41" (10 mm) and 1.00" (25 mm) thick, use the mounting spacer and mounting stud hardware. The faucet sensor cable is threaded through a groove on the side of the shank.

The older mounting kits (Items 12 and 13) can be identified by a copper supply tube attached to the faucet shank, requires an ETF-547 compression fitting, and threads the faucet sensor cable through the interior of the shank.



OLD Optima® ETF-660/ETF-770



PARTS	LIST—ET	F-660 AND	ETF-770	FAUCETS

Item No.	Code No.	Part No.	Description	
1A.	0365162	ETF-595-A	Lavatory Faucet Assembly (ETF-660)	
1B.	0305536	ETF-261-A	Deck-Mounted Gooseneck Faucet Assembly (ETF-770)	
2A.	3365092	ETF-1023-A	0.5 gpm (1.9 Lpm) Spray Head with Key (male thread)	
	3365093	ETF-1024-A	2.2 gpm (8.3 Lpm) Aerator Spray Head with Key (male thread)	
	3365162	ETF-1029-A	2.2 gpm (8.3 Lpm) Laminar Flow Spray Head with Key (male thread)	
	0335927	ETF-435	Replacement Key Only for ETF-1023-A Spray Head and ETF-1024-A Aerator Spray Head (NOT required for F-175-L Laminar Flow Spray Head)	
	3365756	ETF-1039-A	0.35 gpm (1.3 Lpm) Multi-Lam Spray Head VR	
2B.	3365091	ETF-1021-A	0.5 gpm (1.9 Lpm) Spray Head with Key (female thread)	
	3365090	ETF-1022-A	2.2 gpm (8.3 Lpm) Aerator Spray Head with Key (female thread)	
	3365160	ETF-1027-A	2.2 gpm (8.3 Lpm) Laminar Flow Spray Head with Key (female thread)	
	0305927	ETF-435	Replacement Key Only	
	3365755	ETF-1038-A	0.35 gpm (1.3 Lpm) Multi-Lam Spray Head VR	
3.	0305946	EL-3500-A	Microphone-style "On-Q" Sensor Assembly includes O-ring, 18" armored Cable, Microphone Sensor Cap, Locking Pin, Microphone Sensor Body, and Emitter/Detector Shroud	
3B.	0305528	EL-289	Microphone Mounting Kit	
4.	0365524	ETF-199	Cock Hole Cover — OBSOLETE	
5.	0305513	ETF-271	3/8" Tube Fitting Connector (female)	
6.	3365676	ETF-437-A	Single Solenoid Supply Kit includes, two (2) Compression Fittings, Compression Nut, and Ferrule	
7A.	0305849	ETF-370-A	24 VAC Solenoid Valve Assembly includes 18" (457 mm) armored Cable and two (2) Terminal Housings	
7B.	3305577	ETF-1009-A	Solenoid Valve Repair Kit includes Replacement Filter, Guide, Armature Spring, Diaphragm and Washer	
7C.	3375003	MCR-1003-A	Diaphram only	
8.	3365461	ETF-617-A	Bak-Chek® "T" Assembly	
9.	3365000	ETF-450-A	Control Module Assembly includes splashproof Junction Box and Junction Box Mounting Kit	
10.	0365534	ETF-233	120V/35 VA Plug-In Transformer	
11.	0345370	EL-248-40	24V/40 VA Box Mount Transformer	
12.	0365001	ETF-458-A	Input Power Cable (Transformer to Control Module) includes Strain Relief and two (2) Terminal Crimp Connectors	
13.	0305768	EL-310-A	Spout Mounting Kit (ETF-770 Only) Includes Rubber Washer, Steel Washer, Lock Nut, Rubber Cone Washer, and Coupling Nut	
14.	3365602	ETF-432-A	Optional 8" (203 mm) Centerset Trim Plate Kit, includes Seal, Washer Fender, Gasket, Finger Nut, Trim Plate Spacer and Dual Hole Trim Plate Assembly	
15.	3365469	ETF-313-A	Optional 4" (102 mm) Centerset Trim Plate Kit includes Trim Plate Spacer and Dual Hole Trim Plate Assembly	

See page 157 for faucet cable extension cords.

--- = Not shown in illustration

NOTE: For older style ETF-66/77 faucets the replacement EL-350 is discontinued. Replacement is ETF-1019-A includes EL-3500-A and ETF-450-A.

NOTE: For the replacement control module when the older style 3 phone jack module is used, use ETF-492-A.