## CAUTION: PRESSING THUMB TRIGGER DISPENSES FUEL! DO NOT DEPRESS TRIGGER UNTIL SPOUT IS IN FUEL TANK

## INSTRUCTIONS

**1.** Remove spout cap, press down and twist



**2. Rotate spout** into the fuel tank you are filling







**4.** To stop dispensing fuel, **release** thumb trigger

**5. Tilt Can** sideways and towards spout to fully drain before proceeding to step 6. Make sure spout is rotated 180° from the stowed position. Ensure all residual fuel drains from the spout



**6.** Rotate spout to the upright position and **replace spout cap** 

