

Order Replacement Parts

Repair Parts for Model - 3144030

REF. NO.	DESCRIPTION	PART NO.
1	OUTER CASING	16C01
2	TOP FRONT PANEL	16B01
3	BOTTOM FRONT PANEL	16C03
4	TOP TRIM COVER	16A07
5	ELEMENT COVER	16A04
6	JUNCTION BOX ASSEMBLY	16B15
7	ELEMENT CASING BODY ASSEMBLY	16C04
8	MOTOR	P021504
9	RELAY	P154700
10	TRANSFORMER	P154802
11*	LIMIT SWITCH	SEE NOTE BELOW →
12	HEATING ELEMENT	P155001
13	FUSE-LIMITER (2 REQ'D)	P323665
14	TERMINAL BLOCK	P323665
15	MOTOR SUPPORT (2 REQ'D)	16A06
16	FAN BLADE	P200600
17	INTERNAL WIRING	
18	VIBRATION MOUNT-MOTOR (4 REQ'D)	P022800
19	JUNCTION BOX COVER	16A03
20	ORIFICE PLATE	16B05
21	THERMOSTAT	P322016
22	SIDE BAFFLE ASSEMBLY	16A18
☆	OWNER'S MANUAL	P321008

☆ NOT SHOWN

FOR PARTS ILLUSTRATION, SEE PAGE 17.

SCREWS AND BOLTS ARE STANDARD HARDWARE ITEMS, AVAILABLE LOCALLY

* The limit switch, P154900 is not field replaceable and service must be referred to a qualified service technician.