


# Aqua Lux Tub Door & EX/RT Panel

## TUB DOOR AND PANEL INSTALLATION INSTRUCTIONS

### IMPORTANT

DreamLine® reserves the right to alter, modify or redesign products at any time without prior notice. For the latest up-to-date technical drawings, manuals, warranty information or additional details please refer to your model's web page on **DreamLine.com**



**STEP 1: Tub Door Installation Instructions**

**STEP 2: EX/RT panel Installation Instructions**



### Questions?

Please Call **DreamLine** Customer Support: **1-855-831-2126**  
Hours of Operation M-F 8AM - 7PM EST and Saturday 9AM - 5PM EST

**Support@DreamLine.com**



For more information about DreamLine® Shower Doors, Tub Doors & Enclosures, please visit **DreamLine.com**



# AQUA LUX

## Tub Door Installation Instructions

### IMPORTANT

DreamLine® reserves the right to alter, modify or redesign products at any time without prior notice. For the latest up-to-date technical drawings, manuals or additional details please refer to your model's web page on **DreamLine.com**


### Model#

SHDR-3348588-##

### ## finish

-01-Chrome

-04-Brushed Nickel



*Left Hand Installation shown*

Please read these instructions carefully before installing. If you have any questions regarding installation, please contact our technical support specialists Monday through Friday 8:00 AM – 7:00 PM EST at Phone: 1-866-731-2244, Fax: 1-866-857-3638 or e-mail our technical support group at **Support@DreamLine.com**

For more information about DreamLine® Shower Doors & Tub Doors please visit **DreamLine.com**


# Preparation

1. Prior to installation, examine all boxes and packages for shipping damage and compare the piece count with your packing slip. After opening all boxes and packages read this introduction carefully. Check that all of the needed parts are included in the package by checking off the components on the "Parts Diagram". If the unit has been damaged, has a finishing defect, or has missing parts, please contact our customer support department within **3 business days** of the delivery date. **Please note that DreamLine® will not replace any damaged products or missing parts free of charge after 3 business days or if the product has been installed.** Feel free to contact DreamLine® if you have any questions, and please provide an order number, job name or other proof of purchase to help us identify your original order.
2. Please note that you should consult your local building codes with questions on installation compliance standards. Building and plumbing codes may vary by location, and DreamLine® is not responsible for code compliance standards for your project and will not accept any returns.
3. If this unit is going to be installed in a new construction, please install all of the required plumbing and drainage before installing the shower. **Use a competent and licensed (if required by local code) plumber for all plumbing installation.**
4. Please make sure that prior to beginning the installation, the surfaces are leveled and solid and will be able to support the total weight of the unit. Also make sure the walls are at right angles. Irregular installation surface level, radius corners or improper angle of side walls will result in serious problems for your installation. Please, note that some adjustments and drilling might be necessary during the installation process.
5. Please protect all primary surfaces of the product during installation. Never set your glass down directly onto a tile floor. Leave corner protectors in place until necessary to remove them. Always use a piece of wood or cardboard to protect the bottom edge and corners of the glass prior to and during installation.
6. This unit must be installed upon a finished threshold and against finished walls.
7. This model does NOT have any adjustment for out of plumb conditions. Verify that your walls are plumb before proceeding with the installation.
8. **This model requires that you drill into the threshold/tub surface for proper installation.**
9. This model requires a minimum 3/4" of flat threshold space for installation.
10. This model is reversible for left or right hand installation. This manual will show the left hand installation. For a right hand installation, simply begin on the opposite wall and reverse the orientation of the parts as necessary.




**NOTE: DO NOT** install the handle onto the door glass until instructed to do so. **DO NOT** lift the glass using the handle. This could result in damage to the glass and/or serious personal injury. Always use an assistant or a professional grade glass suction cup when handling heavy glass.


## Tools




Tape  
Measure




Pencil



Level



Caulk




Hammer



Power  
Drill




Phillips  
Screwdriver



Drill bit  
(D=5/16")



Drill bit  
(D=1/8")




Knife

**NOTE:** Unpack your unit carefully and inspect it. Lay it out and identify all parts using the detailed diagram and packing list in this manual as a reference. Before discarding the carton, check for small hardware bags that may have fallen to the bottom of the box. If any parts are damaged or missing, please contact DreamLine® for replacement. The shipping boxes may contain extra parts not used in your model configuration.

**NOTE:** Retain these installation instructions for future reference.

## Parts diagram




Part #	Description	Qty	Part #	Description	Qty
01	Stationary glass	1pc	08	Round head screw ST4.2×55	2pcs
02	Support bar	1pc	09	Flanged Side strip	1pc
03	Hinge	2pcs	10	Bottom anti-water strip	1pc
04	Glass door	1pc	11	Bottom bracket	1pc
05	Handle	1pc	12	Round head screw ST4.2×30	1pc
06	Wall Bracket	2pcs	13	Countersunk screw ST4.2×40	1pc
07	Wall Anchor	3pcs			

# Installation steps

**1.** Assemble the **Wall brackets (06)** onto the **Stationary glass (01)**. Use the at least one of the supplied gaskets on each side to protect the glass.

**See Fig 1 for details**




**Fig 1**

**2.** Carefully place the **Stationary glass (01)** onto tub surface. Position it against the wall and level it vertically.

**See Fig. 2 for details**


**Note:** Use a level to make sure the **Stationary glass (01)** is absolutely plumb.



**Fig 2**

**3.** Outline the position of the **Wall brackets (06)** on the wall from inside of the shower area.  
 Set the **Stationary glass (01)** aside.  
 Remove the **Wall brackets (06)** from the **Stationary glass (01)**. Place the brackets back to the outlined positions and mark holes for drilling.  
 Drill the holes in the wall using a  $\varnothing 5/16''$  drill bit and insert the **Wall anchors (07)**. Fasten the **Wall brackets (06)** to the wall using the **Truss head screw ST4.2×55 (08)**.


See Fig 3 for details



**Fig 3**

**4.** Place the **Stationary glass (01)** back onto the tub surface against the **Wall brackets (06)** and level it vertically.  
 Slide the **Bottom bracket (11)** into the notch at the bottom of the **Stationary glass (01)**.

See Fig 4 for details




**Fig 4**

**5.** Mark the drilling hole on the threshold for the **Bottom bracket (11)**.

Set the **Stationary glass (01)** aside.

Drill a hole into the tub surface using an **Ø1/8"** drill bit and fasten the **Bottom bracket (11)** to the tub surface using the **Truss head screw ST4.2×30 (12)**.

**See Fig 5 for details**




**Fig 5**

**6.** Place the **Stationary glass (01)** back into the designated position on the tub. Make any final adjustments, then re-assemble the **Wall brackets (06)** and the **Bottom bracket (11)**.

Install at least one gasket per side to protect the glass from contact with the brackets.

**See Fig 6 for details**



**Fig 6**




**7. Locate the Support bar (02).**

Position the **Support bar (02)** at an angle (ideally 45°) between the glass and the wall. Level it horizontally. Hold it firmly and outline the bracket's position on the wall. Remove the **Support bar (02)** and detach the wall bracket from it. Place the wall bracket against its outlined position on the wall and mark the drilling hole.

Drill a hole using a  $\varnothing 5/16''$  drill bit, insert the **Wall anchor (07)** and fasten the wall bracket to the wall with the **Countersunk Screw ST4.2×40 (13)**.

Attach the **Support bar (02)** to the bracket as shown in Fig. 7.5 and tighten the set screws and the glass holding screw to secure the glass. Be sure to install the gaskets to protect the glass.



**See Fig 7 for details**

**Fig 7**

**8. Align the hinges with the edge of the glass and attach the Hinges (03) to the Stationary glass (01) with the decorative bolts facing inside the shower.**

**\*Bring the Glass door (04) into the tub area and align it with the Stationary glass (01).**


Fasten the **Hinges (03)** onto the **Glass door (04)**.

Make sure the top edges of the **Glass door (04)** and the **Stationary glass (01)** are aligned.


**See Fig 8 & 9 for details**

**\*TIP:** Use a 3/4" shim beneath the door glass to assist with aligning the door glass with the installed hinges and to maintain the proper spacing beneath the door glass.

**Note:** Use the same combination of hinge gaskets on both hinges for the inside and outside hinge plates.





**Fig 8**



**Fig 9**

**9.** Install the **Handle (05)** onto the outside of the **Glass door (04)** only. Make sure to use the supplied gaskets and sleeves to protect the glass. Attach the **Bottom anti-water strip (10)** over the bottom edge of the **Glass door (04)**.

**See Fig 10 for details**



**Fig 10**


**10.** Take three measurements:

- from the top edge of the **Glass door (02)** to the top of the center portion of the top **Hinge (06)** (see Fig 11.1 for an example to use for all three measurements)
- from the bottom of the center portion of the top Hinge to the top of the center portion of the bottom **Hinge (06)**
- from the bottom of the center portion of the bottom **Hinge (06)** to the threshold

Cut the **Flanged side strip (09)** according to the measurements.

Notch the cut strips to be able to slide them into the Hinges and around the installed **Bottom anti-water strip (10)** to cover the space between both glass panels (Figs 11.2, 11.4, 11.6).

With the Glass door open, press the cut strips onto the vertical edge of the **Glass door (02)** as shown.




**Fig 11**

**11.** Apply good quality mildew-resistant silicone along the connection of the stationary glass with the wall and the tub surface.

**Allow 24 hours for the silicone to fully cure before using the shower.**

**See Fig 13 for details**



**Fig 12**

## Product Maintenance

BASES and BACKWALLS: To ensure a long life for your acrylic back walls: wipe them off after each use with a soft cloth. To clean the acrylic back walls use non-abrasive sprays or cream based cleaners. Never use abrasive cleansers, metal brushes or scrapers that could scratch or dull the surface.

GLASS: To ensure long lasting life for your glass shower products: wipe them off after each use with a soft cloth. Rinse and wipe off the glass using either a soft cloth or a squeegee to prevent soap buildup and water spots. To prevent scratching the surface: never use abrasive cleaners and cleaning products that contain scouring agents. Never use bristle brushes or abrasive sponges.

HARDWARE: To ensure a long lasting finish: wipe off the metal parts after each use with a soft cloth. Do not use abrasive cleaners or cleaning products containing ammonia, bleach or acid. If accidentally used, rinse the surface as soon as possible to prevent finish peeling or corrosion. After cleaning the shiny finishes, rinse thoroughly and wipe dry with soft cloth. Never use an abrasive sponge or cloth, steel wool or wired brush as these may permanently scratch the surface.



TEL: 866-731-2244  
FAX: 866-857-3638  
DREAMLINE.COM


For more information on DreamLine® Shower Doors and Enclosure please visit **DreamLine.com**

## EXTENDER Panel (EX) / RETURN Panel (RT)


### EX / RT STATIONARY PANEL INSTALLATION INSTRUCTIONS

#### IMPORTANT

DreamLine® reserves the right to alter, modify or redesign products at any time without prior notice. For the latest up-to-date technical drawings, manuals, warranty information or additional details please refer to your model's web page on **DreamLine.com**



**9" x 58" Extender Panel (EX)**



**30" x 58" Return Panel (RT)**

Right hand installation shown



#### Questions?

Please Call **DreamLine Customer Support: 1-855-831-2126**  
Hours of Operation M-F 8AM - 7PM EST and Saturday 9AM - 5PM EST

**Support@DreamLine.com**



For more information about DreamLine® Shower Doors & Tub Doors please visit **DreamLine.com**


## Table of Contents

Section title	Page #
Aqua Series with Extender (EX) or Return (RT) Panel Model #s	3
Preparation	4
Tools	5
Parts Diagram/Packing List	6
Installation Steps	7-14
Product Maintenance	15




# AQUA series with Extender (EX) or Return Panel (RT) Model #s:

Aqua Tub -EX




SHDR-3148586-EX-01  
SHDR-3148586-EX-04

Aqua Tub -RT




SHDR-3148586-RT-01  
SHDR-3148586-RT-04

AquaLux-Tub -EX




SHDR-3348588-EX-01  
SHDR-3348588-EX-04

AquaLux-Tub -RT




SHDR-3348588-RT-01  
SHDR-3348588-RT-04

Aqua-Ultra Tub-EX




SHDR-3448580-EX-01  
SHDR-3448580-EX-04

Aqua-Ultra Tub-RT




SHDR-3448580-RT-01  
SHDR-3448580-RT-04

Aqua Uno-Tub-EX




SHDR-3534586-EX-01  
SHDR-3534586-EX-04

Aqua Uno-Tub-RT




SHDR-3534586-RT-01  
SHDR-3534586-RT-04

Aqua Fold-Tub -EX




SHDR-3636580-EX-01

Aqua Fold-Tub -RT




SHDR-3636580-RT-01

Aqua Swing-Tub-EX



SHDR-3734580-EX-01

Aqua Swing-Tub-RT



SHDR-3734580-RT-01

**Finish:**  
01- Chrome  
04- Brushed Nickel

## Preparation

1. Prior to installation, examine all boxes and packages for shipping damage and compare the piece count with your packing slip. After opening all boxes and packages read this introduction carefully. Check that all of the needed parts are included in the package by checking off the components on the "Detailed Diagram of Shower Door Components". If the unit has been damaged, has a finishing defect, or has missing parts, please contact our customer support department within **3 business days** of the delivery date. **Please note that DreamLine® will not replace any damaged products or missing parts free of charge after 3 business days or if the product has been installed.** Contact DreamLine® if you have any questions and please provide an order number, job name or other proof of purchase to help us identify your original order.

2. **Please note that you should consult your local building codes with questions on installation compliance standards. Building and plumbing codes may vary by location, and DreamLine® is not responsible for code compliance standards for your project and will not accept any returns.**

3. If this unit is going to be installed in a new construction, please install all of the required plumbing and drainage before installing the shower. Use a competent and licensed (if required by local code) plumber for all plumbing installation.

4. Make sure that prior to beginning the installation, the surfaces are leveled and solid and will be able to support the total weight of the unit. Also make sure the walls are at right angles. Irregular installation surface level, radius corners or improper angle of side walls will result in serious problems for your installation. Please, note that some adjustments and drilling might be necessary during the installation process.

5. Protect all primary surfaces of the product during installation. Never set your glass down directly onto a tile floor. Leave corner protectors in place until necessary to remove them. Always use a piece of wood or cardboard to protect the bottom edge and corners of the glass prior to and during installation.

6. This unit must be installed upon a finished threshold and against finished walls.

7. This model allows for a maximum of 1/2" of adjustment for out-of-plumb wall conditions and 1/4" of adjustment for out-of-level conditions within the u-channel. Use a level to verify the opening conditions before proceeding with the installation.

8. **This model requires that you drill into the threshold for proper installation.**

9. These panels require 5/8" of flat threshold space for installation.

**This manual assumes that the Aqua Series tub door has already been installed.**



**NOTE:** These panels are reversible for left or right hand installation. This manual will show the right hand installation as an example. For a left hand installation, simply begin on the opposite wall and reverse the orientation of the parts as necessary.




**To prevent serious injury, DO NOT lean against the installed panel glass.**


## Tools




Level



Tape Measure



Pencil




Phillips Screwdriver



Drill bit  
( $\varnothing=5/16"$ )




Drill bit  
( $\varnothing=1/8"$ )



Silicone



Power Drill





Hammer

**NOTE:** Unpack your unit carefully and inspect it. Lay it out and identify all parts using the detailed diagram and packing list in this manual as a reference. Before discarding the carton, check for small hardware bags that may have fallen to the bottom of the box. If any parts are damaged or missing, please contact DreamLine® for replacement. The shipping boxes may contain extra parts not used in your model configuration.

**NOTE:** Retain these installation instructions for future reference.

# Parts Diagram



## Packing List

Diagram A					
PART#	DESCRIPTION	QTY	PART#	DESCRIPTION	QTY
01	U-Channel 1 (58" wall profile)	1pc	04	Ø5/16" Wall anchor	4pcs
02	U-Channel 2 (9" bottom profile)	1pc	05	Countersunk screw ST4.2x40	4pcs
03	Extender panel glass	1pc	06	Countersunk screw ST4.2x25	2pcs
Diagram B					
01	U-Channel 1 (58" wall profile)	1pc	04	Ø5/16" Wall anchor	4pcs
02	U-Channel 2 (30" bottom profile)	1pc	05	Countersunk screw ST4.2x40	4pcs
03	Return panel glass	1pc	06	Countersunk screw ST4.2x25	2pcs

# Installation steps

## 9" In-Line Extender Panel Installation (EX)

**NOTE:** The following panel installation instructions apply to all of the Aqua series tub doors. Please install whichever Aqua model tub door you purchased prior to proceeding with the following Stationary Glass installation instructions. Please see the Shower / Tub Door Installation manual included in the door packaging for complete tub door installation instructions.

**NOTE:** Use **Parts Diagram "A"** for the **EX panel** assembly and installation. (Fig 1)

**Note:** The **bottom u-channel (#02)** should measure: **Glass width (+) 3/16"**  
the **vertical u-channel (#01)** should measure: **Glass height (-) 5/8"**

**1.** Slip the **U-Channel 2 (bottom profile) (#02)** and **U-Channel 1 (wall profile) (#01)** onto the **Extender Panel Glass (#03)**. With the door open, place the **Extender Panel Glass (#03)** and **U-Channel** onto the tub surface ensuring that the **U-Channel 1 (wall profile) (#01)** is flush with the wall. (Fig 2.1 and 2.1)

Close the Door Glass and align the **Extender Panel Glass (#03)** (Fig 2.3) Ensure that the **Extender Panel Glass (#03)** is precisely in line with the Door Glass and level it vertically (plumb). (Fig 2.5) Mark the position of both **U-Channels** along the inside edge on the wall and tub surface (Fig 2.6).




Fig 1





Fig 2

**2. Remove the U-Channel 1 (wall profile) (#01) and U-Channel 2 (bottom profile) (#02) from the Extender Panel Glass (#03) and carefully set the Extender Panel Glass (#03) aside.**

Place the **U-Channel 2 (bottom profile) (#02)** back onto the tub surface in line with the inside U-Channel mark. Mark the drill holes on the tub surface through the pre-drilled holes in the **U-Channel 2 (bottom profile) (#02)** and drill the holes using an **Ø1/8"** drill bit.

Apply waterproof silicone along the bottom surface and around the holes of the **U-Channel 2 (bottom profile) (#02)** and fasten it to the tub surface with the **Countersunk Screws ST4.2×25 (#06)**. (**Fig 3**)


**NOTE:** The surface needs to be clean and free of debris before applying silicone.



**Fig 3**

**3. Place the U-Channel 1 (wall profile) (#01) onto the U-Channel 2 (bottom profile) (#02) and align it vertically with the inside U-channel wall mark from the previous step (Fig 4.1). Mark the drill holes on the wall through the predrilled holes in the U-Channel 1 (wall profile) (#01).**


Now drill holes into the wall using a **Ø5/16"** drill bit and insert the **Ø5/16"** **Wall Anchors (#04)**. Apply waterproof silicone along the bottom surface and around the holes of the **U-Channel 1 (wall profile) (#01)** and fasten it to the wall with the **Countersunk Screws ST4.2×40 (#05)**. (**Fig 4**)



**Fig 4**

**4. Apply waterproof silicone into both U-Channels. (Fig 5)**


**NOTE:** The surface needs to be clean and free of debris before applying silicone.



**Fig 5**

**5. Slide the Extender Panel Glass (#03) into the installed U-Channels.**

**NOTE:** If you have difficulty sliding the **Extender Panel Glass (#03)** into the U-Channels, you can use a small block of wood and a rubber mallet to lightly tap on the Extender glass until the glass is firmly set in the U-Channel. Apply a dab of silicone into both open ends of the U-Channels. **(Fig 6)**




**Fig 6**

**6.** Apply a good quality mildew-resistant waterproof silicone along the connection of both U-Channels to the wall and tub surface from the inside of the shower. **(Fig 7)**



**Allow 24 hours for the silicone to fully cure before using the shower.**



**Fig 7**




## 30" Return Panel Installation (RT)

**NOTE:** The following panel installation instructions apply to all of the Aqua series tub doors. Please install whichever Aqua model you purchased prior to proceeding with the following Return Glass installation instructions. Please see the Shower / Tub Door Installation manual included in the door packaging for complete tub door installation instructions.

**NOTE:** Use **Parts Diagram "B"** for the **RT panel** assembly and installation (**Fig 8**)

**Note:** The **bottom u-channel (#02)** should measure: **Glass width (+) 3/16"**  
the **vertical u-channel (#01)** should measure: **Glass height (-) 5/8"**




**Fig 8**

**7.** Slip the **U-Channel 2 (bottom profile) (#02)** and **U-Channel 1 (wall profile) (#01)** onto the **Return Panel Glass (#03)**.

With the door open, place the **Return Panel Glass (#03)** onto the middle of the tub ledge adjacent to the door ensuring that the **U-Channel 1 (wall profile) (#01)** is flush with the wall. Adjust the **Return Panel Glass (#03)** vertically using a level.

Mark the position of both **U-Channels** along the inside edge on the wall and tub surface. (**Fig 9.4**)

Remove the **U-Channel 1 (wall profile) (#01)** and **U-Channel 2 (bottom profile) (#02)** from the **Return Panel Glass (#03)** and carefully set the **Return Panel Glass (#03)** aside. (**Fig 9**)




**Fig 9**

**8.** Place the **U-Channel 2 (bottom profile) (#02)** onto the tub surface in line with the inside **U-Channel** mark. Mark the drill holes onto the tub ledge through the predrilled holes in the **U-Channel 2 (bottom profile) (#02)** and drill the holes using a **Ø1/8"** drill bit.

Apply waterproof silicone along the bottom surface and around the holes of the **U-Channel 2 (bottom profile) (#02)** and fasten it to the tub ledge with the **Countersunk Screws ST4.2×25 (#06)**. (Fig 10)

**NOTE:** The surface needs to be clean and free of debris before applying silicone.




**Fig 10**

**9.** Place the **U-Channel 1 (wall profile) (#01)** onto the **U-Channel 2 (bottom profile) (#02)** and align vertically with the inside U-Channel wall mark from the previous step.

Mark the drill holes on the wall through the predrilled holes in the **U-Channel 1 (wall profile) (#01)**. Now drill holes in the wall using a **Ø5/16"** drill bit and insert the **Ø5/16"** Wall Anchors (#04). Apply waterproof silicone along the bottom surface and around the holes of the **U-Channel 1 (wall profile) (#01)** and fasten it to the wall with the **Countersunk Screws ST4.2×40 (#05)**. (Fig 11)


**NOTE:** The surface needs to be clean and free of debris before applying silicone.



**Fig 11**

**10.** Apply waterproof silicone into both U-Channels. **(Fig 12)**

**NOTE:** The surface needs to be clean and free of debris before applying silicone.




**Fig 12**

**11.** Slide the **Return Panel Glass (#17)** into the groove of the installed U-Channels.

**NOTE:** If you have difficulty sliding the **Return Panel Glass (#17)** into the U-Channels, you can use a small block of wood and a rubber mallet to lightly tap on the Extender glass until the glass is firmly set in the U-Channel.

Apply a dab of silicone to both open ends of the U-Channels. **(Fig 13)**




**Fig 13**

**12.** Apply a good quality mildew-resistant waterproof silicone along the connection of both U-Channels to the wall and tub surface from the inside of the shower. **(Fig 14)**



**Allow 24 hours for the silicone to fully cure before using the shower.**



**Fig 14**

## Product Maintenance

**BASES and BACKWALLS:** To ensure long lasting life for your acrylic back walls: wipe them off after each use with a soft cloth. To clean the acrylic back walls use non-abrasive sprays or cream based cleaners. Avoid the use of aerosol spray cleaners. Never use abrasive cleansers, metal brushes or scrapers that could scratch or dull the surface.

**GLASS:** To ensure long lasting life for your glass shower products: wipe them off after each use with a soft cloth. Rinse and wipe off the glass using either a soft cloth or a squeegee to prevent soap buildup and water spots (Hard water can etch the surface of the glass over time if left to dry). To prevent scratching the surface: never use abrasive cleaners or cleaning products that contain scouring agents. Never use bristle brushes or abrasive sponges that may scratch the surface.

**HARDWARE:** To ensure a long lasting finish: wipe off the metal parts after each use with a soft cloth. Do not use abrasive cleaners or cleaning products containing ammonia, bleach or acid. If accidentally used, rinse the surface as soon as possible to prevent damage to the finish (peeling or corrosion). After cleaning the polished finishes, rinse thoroughly and wipe dry with a soft cloth. Clean stainless steel surfaces at least once a week. When applying stainless steel cleaner or polish to stainless steel hardware, work with (not across) the grain. Never use an abrasive sponge or cloth, steel wool or wired brush as these may permanently scratch the surfaces.

**NOTE: To maximize the life of your product, it is important to regularly inspect the glass and other hardware for misalignment, proper attachment, and/or damage. Contact DreamLine® with any questions or concerns.**



TEL: 866-731-2244  
FAX: 866-857-3638  
DREAMLINE.COM

For more information on DreamLine® Shower Doors and Enclosures please visit [DreamLine.com](http://DreamLine.com)