


## Optima® EAF-900





## Optima® EAF-900

### 1. Faucet does not function properly.

A. pause mode is activated.

End pause mode.

B. Water Supply stop(s) closed. open water supply stop(s).

C. Filter is clogged.

Clean the filter. See page 9.

# 2. Faucet does not stop delivering water or continues to run after

#### user is no longer detected.

A. Reflection.

Set the sensor range or activate automatic sensor adjustment.

# 3. The water temperature is too hot or too cold on a faucet connected to hot and cold water supply lines.

A. Supply stops are not adjusted properly. Adjust supply stops.

### 4. Faucet delivers water continuously.

Contact Sloan Valve Company installation Engineering Department (see below).

#### 5. leak at fittings.

A. Ensure gaskets are installed between fittings for 3/8" compression to g3/8".

B. Tighten fittings.

When assistance is required, please contact Sloan Valve Company installation Engineering Department at:

1-888-SLOAN-14 (1-888-756-2614)